HARNAIS D'ESCALADE SPIDER KID
CLIMBING HARNESS SPIDOR KID

CE

0082

EN 12277:2015 type C

EN 15151-1:2012

EN 15567:2008

WARNING
- Before use, read and understand all english instructions.
- Incorrect use of this protective equipment can cause serious injuries or death.
- Using a damaged or modificated climbing harness can cause serious injuries or death.
- Climbing and mountaineering are inherently dangerous.

DESCRIPTION
CE EN 12277:2015 type C
EN 15151-1:2012 EN 15567:2008
Declaration is not liable for accidents or injuries due to inappropriate use of the harness, negligence, or failure to observe given in the manual, or modifications to the harness by the user.
To avoid serious injury or death, follow the safety information in this manual.

SYMBOLS USED IN THIS MANUAL
Please read this manual carefully before use to ensure that the information contained in the guide is accurate and complete. Contact us if you have any doubts or questions.

assistance.service@petzl.com

Thank you for buying this SPIDER KID SIMOND harness from the PETZL brand.
Petzl, founded in 1970 in Crolles, Alps, it is designed and has been manufactured in Europe for more than 50 years. Petzl is present in more than 130 countries and has a worldwide network of more than 1,000 distributors. Petzl is a leader in personal protective equipment (PPE) providing against fall from a height. Its products are used by professionals and leisure users for work and recreational activities in extreme climates, dark, humid or dusty environments, and in the presence of chemicals, aerosols, etc. and products in general.

WARNING: TRAINING IS ESSENTIAL
Only those who have received adequate training in its use are responsible for keeping the equipment required to perform safely. Training should be given by a qualified person (guide, club, etc.) and under control for activities of height are permitted to use this equipment. Training should be given by a qualified trained for activities of height are permitted to use this equipment. Training should be given by a qualified person and use this product. Insurance and/or a warning are of the responsibility of the user. Petzl is not responsible for damages when the harness is used as part of a fall arrest system.

WARNING: Only use this harness for activities in which the risk of fall is limited to a maximum of 2 m.
Harnesses are designed in accordance with the PPE 2/2016/425 Regulation and tested in accordance with the EN 12277: 2015 standard. Harnesses have been tested in accordance with the EN 15151-1:2012 standard. Harness type C and harness type C with belay loop are tested in accordance with the EN 15567:2008 standard. Petzl harnesses can be used alone or with another type of harness. Petzl harnesses are compatible with Petzl connectors and accessories, except for certain ASAP, Sewn Protection and Adjama models. Using Petzl harnesses with other brands' connectors could result in serious injury or death.

PARTS
A / Tie-in loop
B / Shoulder straps with self-locking buckles
C / Check and Go system

CATALOG
Petzl's SPIDER KID harness has been designed to be used as personal protective equipment that complies with the applicable requirements. Its ergonomic design and numerous options will satisfy most of the needs of the professional and recreational user. Please read this manual carefully and familiarize yourself with the harness' adjustment instructions. Remember to check all of the harness' buckles before each use. Petzl offers a wide range of accessories for this harness.

Fitting the harness
Refer to the illustrations for fitting and for carrying bag and optional accessories.
Put on the harness like a pair of trousers, hold it up in front of you by the shoulder straps with the tie-in loop on the back. Step into the leg loops and pull them up to your waist.
Adjust the leg loops: they should be snug, but not uncomfortable. The gauge should not be too loose, or they may slide off in a fall. Pull the adjustment loop to tighten the leg loop. Pull the buckle flap to adjust the gauge. Fold the flap back over the buckle to hold it in place. Make sure that the webbing can be rolled along the back strips. A split buckle is provided for easy adjustment of the leg loops. Pull the adjustment loop to tighten the leg loop. Pull the buckle flap to adjust the gauge. Fold the flap back over the buckle to hold it in place. Make sure that the webbing can be rolled along the back strips. A split buckle is provided for easy adjustment of the leg loops. Pull the adjustment loop to tighten the leg loop. Pull the buckle flap to adjust the gauge. Fold the flap back over the buckle to insert it (image 4).
Adjust the waist belt: it should be snug, but not uncomfortable. Pull the adjustment loop to tighten the belt. Pull the buckle flap to adjust the gauge. Fold the flap back over the buckle to hold it in place.
When using the SPIDER KID harness, check the adjustment of the leg loops and waist belt regularly as it may slip.

Buckles
We recommend the use of a double-open knot with your harness (see image 5). Pass the rope through the tie-in loop on the front of the harness and tie a knot. Warning: you can tie an overhand knot or a figure-of-eight knot, but only when you are using tools or activities where there is no risk of fall. Always check the knot before continuing.

Selecting
To choose another climber, connect a belaying device to your harness' tie-in loop and belay as you would normally.

Check & Go system (image 6)
The Check & Go system is designed to prevent by facilitating the visual check of the harness' buckles. Before each use, check that the buckles are correctly fastened and are secure. The Check & Go is designed to make the learning of climbing knots easier. Follow the instructions in this manual for correct use.
Step 1: Pass the rope through the tie-in loop on the front of the harness.
Step 2: Pass the rope through the Check & Go system.
Step 3: Tie a knot.
Step 4: Tighten the system up to the Check & Go system's indicator.
Step 5: Check the knot.

CARE AND STORAGE
Clean the harness with a soft cloth or with warm clear water and mild soap. Rinse it in clear water and let it dry away from all sources of heat. Allow it to dry in the open air, away from direct sunlight. Store your harness in a dry, cool, dark place, away from all sources of heat and chemicals.

CARE AND STORAGE
Clean the harness with a soft cloth or with warm clear water and mild soap. Rinse it in clear water and let it dry away from all sources of heat. Allow it to dry in the open air, away from direct sunlight. Store your harness in a dry, cool, dark place, away from all sources of heat and chemicals.

INSPECTION AND RETURN
Petzl recommends that each piece of the product is forbidden. Put the harness under the following circumstances: Overweight Damaged, Modified, Contaminated.

CHECKS AND LIFE SPAN
Before
Before each use, you should check the condition of your SPIDER KID harness:
- Check the harness' entire outer surface for signs of wear, cuts, abrasions, chemical damage, or burns. Also check the condition of the stitching on the harness. Be especially alert to sunken or abrasion. Be especially alert to sunken or abrasion.
- Check the harness' buckles, webbing, and stitching. Make sure that the buckles are correctly fastened and secure.
- Check the harness' buckles, webbing, and stitching. Make sure that the buckles are correctly fastened and secure.
- Check the harness' buckles, webbing, and stitching. Make sure that the buckles are correctly fastened and secure.

DURING
Using it and storing it. If in doubt about the use of your harness, contact Petzl or a qualified person. Using it and storing it. If in doubt about the use of your harness, contact Petzl or a qualified person or destroy it.

Lifespan
The maximum service life of SIMOND products, considered as personal protective equipment, is 10 years from the date of manufacture indicated on the product, or 10 years for harnesses.
The service life is limited from the date of manufacture of the product, or 10 years for harnesses.
Petzl strongly recommends that you retire your harness after 10 years for harnesses.
Petzl strongly recommends that you retire your harness after 10 years for harnesses.
Petzl strongly recommends that you retire your harness after 10 years for harnesses.
Petzl strongly recommends that you retire your harness after 10 years for harnesses.

WARRANTY
Petzl's products are guaranteed against defects in workmanship and materials for a period of 2 years from the date of purchase. This guarantee does not cover normal wear, accidents, or anything from improper use or modifications to the product. Petzl's liability is limited to repair or replacement of the product.

USE
Refer to the user guide before using this equipment

SIMOND logo

Harness DECATHLON type, group that SIMOND belong

Petzl Petzl's recommendations also take precedence over those of the product regards the CSIA's ISO safety label

Petzl Petzl's recommendations also take precedence over those of the product regards the CSIA's ISO safety label

Petzl Petzl's recommendations also take precedence over those of the product regards the CSIA's ISO safety label

Petzl Petzl's recommendations also take precedence over those of the product regards the CSIA's ISO safety label